



Parts List for 46-460 Type 1

Item Number	Part Number	Description	Qty Required
1	5140059-91	HANDWHEEL	1
2	5140059-92	WAVE WASHER	1
3	5140059-93	BALL BEARING	1
4	5140059-06	PULLEY	1
5	5140059-94	DRIVE BELT	1
7	5140059-09	LOCK WASHER	1
9	5140059-22	SET SCREW	9
10	5140066-28	BRACKET	1
11	5140034-78	CAP SCREW	5
12	5140066-29	DOWEL PIN	1
13	5140066-30	DOOR	1
14	5140059-24	DOWEL PIN	1
15	5140060-39	INDEX PIN	1
16	5140059-26	SPRING	1
17	5140060-40	RETAINING RING	1
18	5140060-41	SCREW	4
19	5140060-42	HEADSTOCK	1
20	5140060-43	BALL BEARING	1
21	5140060-44	KEY	1
22	5140059-31	SPINDLE	1
23	5140059-89	SPUR CENTER	1
24	5140033-43	WASHER,EX TOOTH	2
25	5140060-45	SCREW	4
27	5140060-46	DOOR	1
28	5140059-32	FACE PLATE	1
29	5140060-47	BED	1
30	5140060-48	WASHER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 46-460 Type 1

Item Number	Part Number	Description	Qty Required
31	5140059-40	SCREW	4
32	5140059-41	BELT TENSION LEVER	1
33	5140055-74	CORD CLAMP	2
34	5140054-51	SCREW	4
35	5140059-43	RUBBER COVER	2
36	5140059-87	PLATE	1
37	5140059-45	TOOL REST	1
37	5140059-01	TOOL REST	1
39	5140059-83	RETAINING RING	1
40	5140059-47	ADJUSTING SHAFT	1
41	5140059-48	COLLAR	2
42	5140059-82	NUT	4
43	5140060-49	WRENCH	1
44	5140059-84	RETAINING RING	1
45	5140059-85	TOOL REST BRACKET	1
46	5140059-51	LOCK HANDLE	2
47	5140059-81	LIVE CENTER	1
48	5140059-88	SCREW	2
50	5140059-52	WAVY WASHER	3
51	5140056-03	WASHER	4
52	5140059-53	QUILL	1
53	5140059-86	TAILSTOCK	1
54	5140032-25	NUT	1
55	5140059-55	RETAINING RING	1
56	5140059-56	ECCENTRIC SHAFT	1
57	5140059-57	HANDWHEEL	1
58	5140059-58	LEAD SCREW	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for 46-460 Type 1

Item Number	Part Number	Description	Qty Required
59	5140059-59	SHAFT	1
60	5140060-50	HANDLE	1
61	5140059-61	SHOULDER SCREW	1
62	5140059-62	KNURLED NUT	1
63	5140059-63	BRACKET	1
64	5140059-64	PULLEY	1
65	5140032-44	CAP SCREW	2
66	5140060-51	WASHER	1
67	5140059-67	FRONT PANEL	1
68	5140059-68	BRACKET	1
69	5140060-54	BRUSH CAP	2
69	5140060-53	BRUSH	2
69	5140060-52	MOTOR	1
70	5140060-55	MOTOR BRACKET	1
71	5140059-71	WASHER	2
72	5140060-56	SHOULDER SCREW	3
77	604407-02	HEX WRENCH	1
79	5140066-35	PIN	1
83	5140059-80	KNOCK OUT BAR	1
84	5140059-44	ECCENTRIC SHAFT	1
92	5140066-36	SPRING PLATE	1
93	5140056-20	SCREW	2
95	5140059-73	SHOULDER SCREW	2
96	5140059-74	ADJUSTMENT ROD	1
98	5140056-15	HEX NUT	1
105	A29474	SPEC. LABEL	1
107	A29471	SPEC. LABEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 46-460 Type 1

Item Number	Part Number	Description	Qty Required
112	A25399	SPEED CHART	1
113	A25400	SPEED CHART	1
114	A25392	LABEL	1
200	5140059-95	SCREW	4
201	5140059-11	REVERSING SWITCH	1
202	5140059-12	KNOB	1
203	5140059-13	SET SCREW	1
204	5140059-14	ON/OFF SWITCH	1
205	5140059-15	SPEED CONTROLLER	1
206	5140059-16	STRAIN RELIEF	2
207	5140059-17	CONTROL BOX	1
208	5140059-18	LEAD ASSY.	6
209	5140059-96	OVERLOAD	1
210	5140059-20	LEAD ASSY.	1
211	5140059-21	LEAD ASSY.	2
216	5140059-90	CENTER	1
217	5140059-97	FOAM SEAL	1
218	5140059-98	FOAM SEAL	1
219	5140059-99	FOAM SEAL	1
220	5140060-36	FOAM SEAL	1
221	5140060-37	CORDSET	1
222	5140059-02	CENTER	1
223	5140063-58	COVER	1
224	5140063-59	ACTUATOR	1
225	5140063-67	SCREW	1
226	5140063-68	ACTUATOR	1
856	46-463	BED EXTENSION	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 46-460 Type 1

Item Number	Part Number	Description	Qty Required
856	46-461	CHUCK	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.